

LAYING OUT A SHOWER HOB

STEP 1

- Clean up the area. Thoroughly remove any dirt and dust.
- Measure up and decide where the hob will be placed.
- Mark the area on the floor.

STEP 2

- Make sure that the area is square to the walls.
- Always double check your measurements. Measuring diagonally across the area (both ways) is a good double check for square.

STEP 3

- Using Hebel blocks to form the hob, we need to measure and cut the blocks to size. These blocks can be cut with a hand saw. Don't make the hob (step) too high because you will need to step over it every day. (100mm is a good height)
- Lay them in place

STEP 4

- Mix some tile adhesive. (Beaumont Tiles Floorflex is ideal)
- Always add the water to the bucket first and then add the powder. (follow the directions on the pack)
- Mix to a paste type consistency.

STEP 5

- Glue the blocks into place. It is a good idea to place some adhesive to the floor and wall, then some more onto the block. This ensures a good coverage to a depth of about 4mm thick.
- Double check for level and square once all the blocks are in place and leave for 24 hours for the adhesive to set.



TIP

When cutting the Hebel Blocks, better to measure twice and cut once!