

FITTING ACCESSORIES

So, the area is tiled and grouted. Our silicone joints are all finished and it is almost time to celebrate a job, well done. All we need to do now is fix our accessories.

STEP 1

- Decide where each fitting will be fixed.
- Mark the centre of the fixing position.

STEP 2

- Apply some tape on the centre mark. (this will stop your drill bit from slipping over the glazed tile surface)
- Mark the exact drill hole positions.

STEP 3

- Make a, 'well' under the drill hole spots, to collect the dust once we start drilling.

STEP 4

- Drill the holes to suit the plugs and screws supplied with the fittings.

STEP 5

- Inset the plugs, screws and then fit the accessory.



TIP

There are special chrome, brass and stainless steel grates available for the floor waste outlet (even gold plated for the very discerning.)

