



CFLEX SHOWER NICHE



Fixing the Niche in to a new wall:

- Locate the position of niche on wall
- Add noggins to studs, both top and bottom of niche position for secure fastening
- Continue on with either the flush mounted or feathered installation instructions



Fixing the Niche in to an existing finished wall:

- Locate and mark the center of adjacent framing studs using a stud finder or by tapping the wall
- Draw a level line between the two wall studs
- Place the niche between the two marked studs. Be sure niche is level.
- Trace around back of niche, not including the mounting flange
- Cut out the wall board along the traced lines between the two studs using a drywall saw and utility knife
- Continue on with either the flush mounted or feathered installation instructions



TWO METHODS OF INSTALLATION:

1. Flush Mounted Installation Instructions:

- In some substrates, you may be able to grind the perimeter of the cut out for the width and depth of the mounting flange prior to unit installation.
- Add a continuous bead of silicone on the back of the mounting flange. Secure Niche to the studs and noggins with wall fasteners (Not supplied – 8 gauge – 10 thread x 30mm recommended). A power screwdriver may be used on a low resistance setting. Tighten all fasteners by hand and don't over tighten.
- Apply Waterproofing Tape around edges and then apply waterproof membrane to substrate and niche (Follow manufacturers instructions).
- Apply your setting material using polymer modified adhesive and set your tile, marble or stone directly to shower Niche

2. Feathered Installation Instructions:

- Add a continuous bead of silicone on the back of the mounting flange. Secure Niche to the studs and noggins with wall fasteners (Not supplied – 8 gauge – 10 thread x 30mm recommended). A power screwdriver may be used on a low resistance setting. Tighten all fasteners by hand and don't over tighten.
- Apply Waterproofing Tape around edges and then apply waterproof membrane to substrate and Niche (Follow manufacturers instructions).
- Thickness of mounting flange should be minimized to provide a flush wall surface for the finish tile. Feather out the flange to the substrate using a polymer modified adhesive.
- Apply your setting material and set your tile, marble or stone directly to shower Niche

