CFLEX SHOWER NICHE

Fixing the Niche in to a new wall:

a. Locate the position of niche on wall
b. Add noggins to studs, both top and bottom of niche position for secure fastening
c.Continue on with either the flush mounted or feathered installation instructions





Fixing the Niche in to an existing finished wall:

a. Locate and mark the center of adjacent framing studs using a stud finder or by tapping the wall
b. Draw a level line between the two wall studs
c. Place the niche between the two marked studs. Be sure niche is level.
d. Trace around back of niche, not including the mounting flange
e. Cut out the wall board along the traced lines between the two studs using a drywall saw and utility knife
f. Continue on with either the flush mounted or feathered installation instructions





TWO METHODS OF INSTALLATION:

1. Flush Mounted Installation Instructions:

a. In some substrates, you may be able to grind the perimeter of the cut out for the width and depth of the mounting flange prior to unit installation.
b. Add a continuous bead of silicone on the back of the mounting flange. Secure Niche to the studs and noggins with wall fasteners (Not supplied – 8 gauge – 10 thread x 30mm recommended). A power screwdriver may be used on a low resistance setting. Tighten all fasteners by hand and don't over tighten.
c. Apply Waterproofing Tape around edges and then apply waterproof membrane to substrate and niche (Follow manufacturers instructions).
d. Apply your setting material using polymer modified adhesive and set your tile, marble or stone directly to shower Niche

2. Feathered Installation Instructions:

a. Add a continuous bead of silicone on the back of the mounting flange. Secure Niche to the studs and noggins with wall fasteners (Not supplied – 8 gauge – 10 thread x 30mm recommended). A power screwdriver may be used on a low resistance setting. Tighten all fasteners by hand and don't over tighten.
b. Apply Waterproofing Tape around edges and then apply waterproof membrane to substrate and Niche (Follow manufacturers instructions).
c. Thickness of mounting flange should be minimized to provide a flush wall surface for the finish tile. Feather out the flange to the substrate using a polymer modified adhesive.
d. Apply your setting material and set your tile, marble or stone directly to shower Niche





