



SPIN KING TILE LEVELLING SYSTEM

- Caps secure to spacer by spinning the cap to tighten
- Kick the cap and spacer along the grout joint to remove
- Use a white rubber mallet to remove from walls
- · Ideal for floors and walls
- Designed to level lippage on tiles when laying
- Suits 3mm to 18mm tile thickness
- Spacers available in 1.5mm and 3mm
- · Caps are reusable
- · No tool required

