

# DIAREX<sup>®</sup>



## DIAREX<sup>®</sup>

### SAFETY PRECAUTIONS

- ▶ Never work without safety guard, safety gloves or safety glasses.
- ▶ Never hold the material being cut in your hand, or secure it using your leg or foot during sawing.
- ▶ Do not use the blade as a grinding wheel.
- ▶ Only use for straight cuts.
- ▶ Inspect blade for visible signs of damage before use.
- ▶ Do not overheat – allow to cool.

CERAMIC	✓✓✓✓✓
PORCELAIN	✓✓✓✓✓
HARD STONE	✓✓✓✓✓
SOFT STONE	✓✓✓✓✓
ENGINEERED STONE	✓✓✓✓✓

MAXIMUM  
CUTTING  
DEPTH 15MM

DIAMETER  
**125mm**  
MAX. RPM  
**12,000**

- ▶ For use with Ceramic, Porcelain, Sintered Stone, Natural Stone & Engineered Stone.
- ▶ Be sure electrical cord is unplugged during blade installation or removal.
- ▶ The blade should be mounted with the arrows pointing in the direction of rotation.
- ▶ Make sure that you are using the proper blade specifications for the material being cut.
- ▶ Make sure the bore of the saw blade is correctly matched to the diameter of the blade mount.
- ▶ If you are unsure on the safety of a diamond blade, do not continue using the blade.

