

DIAREX[®]

ENS
SEGMENTED BLADE

DIAREX[®]

SAFETY PRECAUTIONS

- Never work without safety guard, safety gloves or safety glasses.
- Never hold the material being cut in your hand, or secure it using your leg or foot during sawing.
- Do not use the blade as a grinding wheel.
- Only use for straight cuts.
- Inspect blade for visible signs of damage before use.
- Do not overheat – allow to cool.

CERAMIC	✓✓✓✓✓
PORCELAIN	✓✓✓✓✓
HARD STONE	✓✓✓✓✓
SOFT STONE	✓✓✓✓✓
SINTERED STONE	✓✓✓✓✓

MAXIMUM
CUTTING
DEPTH 15MM

DIAMETER
125mm
MAX. RPM
12,000

- For use with Ceramic, Porcelain, Natural Stone, Engineered Stone + Sintered Stone.
- Be sure electrical cord is unplugged during blade installation or removal.
- The blade should be mounted with the arrows pointing in the direction of rotation.
- Make sure that you are using the proper blade specifications for the material being cut.
- Make sure the bore of the saw blade is correctly matched to the diameter of the blade mount.
- If you are unsure on the safety of a diamond blade, do not continue using the blade.

